
ISO175 IMD

Points of contact from bender:

- daniel.woelfel@bender.de (CAN stuff)
- <u>torsten.gruhn@bender-us.com</u> (hardware stuff + sponsorship)

All manuals are in github

Testing setup:



- Pin 1 is chassis and pin 3 is ground. They don't necessarily need to have the same potential (there should be a configuration for it). For our purposes, though, chassis ground and low voltage ground are one thus we connect those together.
- The OK status signal is is active low signal. Without the Rtest resistor the signal should be high. When a Rtest value below a certain threshold (default 100kOhms) is used, the OK status signal will drop after maybe 15ish seconds.

Changing configurations

The baudrate for the unit we have is 250kB. The CAN frames are in a format defined by the SAEJ1939 protocol hence we need to use that manual. This protocol uses PGNs (parameter group numbers) instead of standard CAN ids. So if you see a number like 61428 in the manual, you can convert it online. I feel like some of the online converters are incorrect though. I'd also refer to the customer_commands.xmt file for writing/setting configurations.

- I handled all CAN on an arduino during testing. When you connect the bus then power on the IMD, after 2 seconds, it will read a message with ID 0x1CEBFFF4. This is the DeviceInfoMessage.
- Additionally every 100ms you'll get the Info_general message with ID 0x18FFABF4. I'd recommend filtering this id out of the messages displayed on serial monitor.
- Reading threshold resistance:
 - unsigned char stmp[1] = {0x46};
 - CAN.sendMsgBuf(0x18EFF417, 1, 1, stmp);
 - Response: 0x18EF17F with data {0x46, 0x64, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF, 0xFF}
 - The value is in the first 1st data bit (not 0th). 0x64 = 100, meaning 100kOhm
- Setting threshold resistance:
 - Per industry standards and FSAE rules, the isolation requirement is 500*HV. Since we are using 400V this year, we need 200kOhms of isolation.
 - unsigned char stmp[3] = $\{0x47, 0xC8, 0x00\}$;
 - CAN.sendMsgBuf(0x18EFF417, 1, 3, stmp);
 - No response
 - 0xC8 = 200